

# LOWREY



Songs  
side

EASY

BASIC

MCS Magic

ABC's  
A<sup>#</sup>B C<sup>#</sup>D

# Fiesta

# Easy Play is the Lowrey Way!

Sound great playing your favorite songs with the Fiesta's 24 fully-orchestrated rhythm styles. Each **Style Category** contains 2 Rhythms plus one **Basic Style** (listed in *Italics*). Be the conductor of your very own orchestra with unique **Rhythm Features**.

## Rhythm Styles

### BIG BAND

Swing Band  
San Frans

*Basic 4/4*

### COUNTRY

Easy Country  
The Train

*Basic Country*

### BROADWAY

The Broadway  
Sleigh Bells

*Basic Dbl. Time*

### MARCH

Thundering 4/4  
Grand March

*Basic March*

### SOFT & EASY

Easy 4/4  
Guitars

*Soft Basic*

### WALTZ

Easy Waltz  
Country Waltz

*Basic 3/4*

### FOX TROT

Champagne  
Charleston

*Basic Fox/Swing*

### GOSPEL

Joyful Revival  
Church Organ

*Basic Gospel*

### HAWAIIAN

Aloha

Paradise

*Basic Hawaiian*

### EASY LATIN

Bossa Plus

Rhumba/Beguine

*Basic Latin*

### BALLAD

50's Slow 6/8

Ballad Triplets

*Basic Ballad*

### POLKA

Polka Band

Happy Polka

*Basic Polka*

## Features

Orch Plus Volume

Rhythm Volume

Rhythm Tempo

MCS

Genie

Orch Plus

Rhythm Preset

Variation

Auto Bass

Intro/Ending

Start Stop

Memory

FX

*Basic*

## General Presets

Just press one of the 8 General Preset buttons and you are ready to play. Each button provides a different sound.

*Have you ever come up with that "perfect" sound only to lose it once your organ was shut off?*

Capture that sound and keep it by using the **Memorize** button to save your own creations to any General Preset button.

## Orchestral

Orchestral Volume

Upper On

Vibes

Lower On

Electric Piano

Piano

Country Guitar

Jazz Guitar

Hawaiian Guitar

Banjo

Trombone

Accordion

Marimba

## SOLO

Sole Volume

Sax

Upper On

Bells

Trumpet

Chimes

Violin

Clarinet

## Upper

String Volume

Strings

Sustain Long

Sustain Medium

Flute 16

Flute 8

Flute 4

Mellow Organ

Pipe Organ

## Information Center

The Information Center window displays important data: Rhythm Tempo, Chord and Bass Pedal played. The **Transpose** buttons make it easy to play in a different key. The **Easy** button initiates all the easy-play features with just one button: MCS, Auto Bass, and Chord Memory. Press the **Play Along** button to listen to, or play along with, the 25 songs inside the Fiesta! Each song is in the Lowrey Songbook so you can play along. **Song Select** displays the song titles in the Information Center window. Press the **Play Stop** button to hear the song displayed in the window.

## Harmony

ABC is a unique Lowrey feature that makes your one finger note sound like you are playing many notes-all in perfect harmony.

## Vibra Trem

Adds authenticity to the upper flute and organ sounds by duplicating the effect of a spinning speaker.

**ABC's**  
Flip the ABC's switch and all the keys become brightly labeled.

**Master Volume** sets the overall volume of the Fiesta and leaves it there until you change it. **Reverb** adds depth and resonance to the sounds of the Fiesta

**Bass Lower**  
Bass Volume Bass 16  
Bass 8 Ensemble Bass  
Lower Volume  
Strings Vocal  
Flute 8 Flute 4

**MCS**  
**Music Chord System** is Lowrey's easy-play chord device. **MCS** lights effortlessly guide you. Just follow the **Red**, **Blue**, and **Green** color bars in the Lowrey Songbook, Lowrey Magic Organ Course books, or Theme Songs.



**Dimensions:** 23.75" deep  
41" high *Cabinet + Music Rack 48"*  
42.5" wide. Weight w/bench: 158 lbs.  
**Connections:** Stereo Headphones,  
Aux. In/Out-Left Right  
**MIDI** in-out-thru

## Audio System

Live Performance sound quality is delivered through a two-speaker stereo sound system:  
25 watts/channel (50 watts total)  
2 - 6"x9" dynamic-range speakers

LOWREY  
825 East 26th, LaGrange Park, IL. 60526  
708-352-3388, www.lowrey.com