

Teenie Genie



LOWREY TEENIE GENIE (Model TG). . . The Entertaining Magic of **ONE-FINGER Genie Chords!** Now. . . a multitude of songs can be played and enjoyed using only *two fingers* on a single keyboard. No need to learn to play pedals either. How? Really simple.

First, press one of the Rhythm tabs along with the "Accompaniment - Genie Chords" tab. Now, select a song from one of your specially prepared Lowrey song books and that's it. . . you're ready to play.

With the *left* index finger, press one of the 14 magical Genie Chord keys. This one note will give you a three-note chord complete with Automatic Rhythm, Automatic Accompaniment and Automatic String or Guitar Bass. With the *right* index finger, simply pick out the easy to follow melody on the right-hand keys.

In addition to the One-Finger Genie Chord feature, Teenie possesses the Genie capability of allow-

ing you to play the regular three-finger, three-note chord complete with Automatic Rhythm, Automatic Accompaniment and Automatic Bass.

Teenie also comes equipped with variable Sustain, six delightful Presets and four realistic Rhythms that can be combined to create a number of Rhythm variations.

A completely solid-state, Large Scale Integrated Circuit (L.S.I.C.) and transistor, self-contained home organ with one 57-note keyboard that consists of 20 left-hand notes with regular Genie and Bass and 37 right-hand notes. (The 20 left-hand notes also include the 14 One-Finger Genie Chords with Bass.)

The organ also includes a 25-watt amplifier, a 12" full-range speaker with a 3" whizzer cone and a headphone jack for playing in privacy. (Monaural or stereo headphones can be used.)

Dimensions: 34-1/8" high (without music rack), 36-3/4" wide and 20" deep. Weight: 90 lbs.

Available in Vintage Walnut.

RIGHT HAND (Pg.66)

CUSTOM VOICING

Flute
Horn
Reed
String
Vibrato

CUSTOM SUSTAIN

Sustain Control. . . Short/Long

SUSTAIN/PERCUSSION PRESETS

Vibra Harp
Hawaiian Guitar
Piano
Harpsichord
Mandolin
Banjo

LEFT HAND (Pg.67)

BASS

Bass. . . String Bass/Guitar Bass
Bass. . . Full

GENIE ACCOMPANIMENT

Piano
Guitar
Banjo
Accompaniment. . . Full
Accompaniment. . . Genie/Genie Chords

GENERAL CONTROLS

Expression Pedal (Pg.41)
Glide Control (Pg.44)
On/Off Switch with Pilot Light (Pg.41)

AUTOMATIC RHYTHM (Pg.68)

AUTOMATIC RHYTHM PATTERNS

Latin
Rock
Swing
Waltz

RHYTHM CONTROLS

Rhythm Start. . . Normal/Auto
Rhythm Volume. . . Soft/Full
Rhythm/Repeat Speed. . . Slow/Fast

GENIE CHORDS

KEYS AND CHORDS

<u>Key Note</u>	<u>Gives this Chord</u>
A ₁	A Major
A# ₁	A Minor
B	B Major
C	C Major
C#	C Minor
D	D Major
D#	D Minor
E	E Major
F	F Major
F#	F Minor
G	G Major
G#	G Minor
A ₂	E _b Major
A# ₂	B _b Major