

Performer Rhythm Style Table

144 Fully-Orchestrated Rhythm Styles

Panel Name	Variation 0	Variation 1	Variation 2	Variation More		
				Mellow	Exciting	Basic
BIG BAND	Swing Band	Swing Train	<i>Chicago Swing</i>	Bert's Bounce	Boogie Woogie	Basic Big Band
FOX TROT	Champagne	Charleston	Dixieland	Tap/Soft Shoe	Razz-ma-Tazz	Basic Fox Trot
SWING	Serenade	Autumn Keys	Harmoni-Cats	San Frans	Swing & Sway	Basic Swing-Hop
COUNTRY 1	Country Swing	The Train	Texas Toe-Tapper	Crazy Country	Bluegrass	Basic Country 1
COUNTRY 2	EZ Country	Roadside Café	Country Shuffle	On The Trail	Boot Scootin'	Basic Country 2
GOSPEL	Revival	Church Organ	Shoutin'	Soulful	Hand Clappin'	Basic Gospel
BROADWAY	Opener	Sleigh Bells	Theatre Organ	New York Swing	Vegas Big Band	Basic Broadway
MARCH	Thundering	Grand March	Swing March (6/8)	<i>Toys</i>	A Few Patriots	Basic March
POLKA	Happy Polka	Bavarian Polka	Cajun / Zydeco	<i>Folk Wedding</i>	Can - Can	Basic Polka
SOFT & EASY	EZ 4 / 4	Guitars	Soft Gospel	Smooth Piano 4/4	Roses	Basic Soft & Easy
BALLAD	50's Love Songs	Cat Memories	<i>Soul Ballad</i>	Smokey Lounge	Theatre Romance	Basic Ballad
HAWAIIAN	Aloha	Paradise	Gone To Maui	Calypso	Ukulele Luau	Basic Hawaiian
ROCK'N ROLL	50's Swing Rock	Old Time Rock	Bandstand	Soft Rock	Fab-4	Basic Rock
CONTEMPO	Folk	Disco	70's Love Song	<i>Meditation</i>	Surf's Up	Basic Contempo
POP	50's Pop Vocal	Doo-Wopp	<i>Sand-ee-Man</i>	Spots of Ink	Sammy D Candy Jr.	Basic Pop
LATIN 1	Bossa Nova	Rhumba/Beguine	Cha Cha	Bolero	Salsa	<i>Basic Latin 1</i>
LATIN 2	Samba	Tango	Mambo	Habanera	Mariachi	Basic Latin 2-Conga
RHYTHM & BLUES	Chicago Blues	Slow EZ Blues	Organ Blues	L.I.F.E.	Motown/Funky	<i>Basic R & B</i>
WALTZ 1	Easy Waltz	Country Waltz	Carousel	Smooth Piano 3/4	Guitars 3/4	Basic Waltz 1
WALTZ 2	Viennese Waltz	Oom-Pah-Pah	Bojangles	<i>Lullaby</i>	Chipmunks	Basic Waltz 2
RAGTIME	Joplin Stride	Honky Tonk	Gazebo Waltz	<i>Burlesque</i>	Quickstep	Basic Ragtime
TRADITIONAL	Mexican 3 / 4	Radio City	Epic Movie	McSwing	<i>Bagpipes</i>	<i>Basic Traditional</i>
CLASSIC	Symphonic	Baroque	<i>Square Dance</i>	Strings 101	Classic Western	Basic Classic
SPECIAL	Like - Spike	Frank & The Count	Dean - Oh!	<i>Candelabra</i>	Mr. Showman	Basic Special-Rain

The Performer features a world wide selection of dynamic rhythm styles.

Each blue style button holds a total of six distinctive rhythm variations. For example, press the blue **Classic** button and you get a style called **Symphonic**. Press the blue **Variation 1** button and you get **Baroque**. The **Variation 2** button holds a style called **Square Dance**. Press both Variation buttons at the same time for **More!** Three additional variation categories appear on the Color Touch Screen: **Mellow** - **Strings 101**, **Exciting** - **Classic Western** and **Basic** - **Basic Traditional**. Adding to all this variety is the **Performer's** numerous easy-play and rhythm control features. Control how much of a style is heard with **Genie** and **Orch Plus**. **Drum Variation** changes the drum pattern in a style and **Drum Only** plays just the drum portion of a style. **Alter Style** makes changes to a rhythm style, adding even more variety to the rhythm section. **Auto Bass 1** or **Auto Bass 2** plays the bass pedals for you. **MCS** is Lowrey's famous easy-play chord system and **Memory** holds the last MCS chord played even after the key is released. **Intro/Ending** adds professionally-scored beginnings and endings to your songs. **Start Stop** begins and pauses a style. Add a break or fill-in with **FX**. **Fade-Out** causes the ending of a style to slowly fade away at the end of a song.

The 130 Rhythm Styles listed in **standard type** feature a Minor Chord Introduction. In addition to the regular Introduction, these 130 styles have a unique Introduction when started by playing a Minor Chord.

The 14 Rhythm Styles listed in *Italics* do not feature a Minor Chord Introduction.

LOWREY

Performer Specifications

Rhythm Plus Orchestration	144 fully-orchestrated styles. Control features include: Alpha Style Listing, Genie, Orch Plus, Auto Bass 1 & 2, Drum Variation, Tempo, Alter Style, Drum Only, MCS (Music Chord System), Memory, Easy, Variation 1 - 2 - More (Variations Mellow, Exciting, Basic), Intro/Ending, Start Stop, FX, Drum Volume, Rhythm Preset
Presets	2,225 Total Presets. Power Up-1; General Presets-10; Category Presets-90 <i>10 per category: Country, Big Band, Show, Latin, Sacred, Bells, Nostalgic, Holidays, Lush</i> ; Bank Presets-40: <i>10 per bank: A, B, C, D (programmable)</i> ; Song Set Up-500; Rhythm Presets-1,584
Touch Screen	Full Color - 320 x 240 Liquid Crystal Display "Touch Sensitive" Screen
Orchestral Sounds Features	Piano, Jazz Guitar, Accordion, Vibes, Electric Piano, Country Guitar, Trombone, Marimba, Banjo, Hawaiian, Genius 1, Genius 2 Volume, Upper On, Lower On, Dynamic Keying, Upper Octave
Solo Sounds Features	Society Piano, Trumpet, Violin, Bells, Sax, Jazz Flute, Chimes, Genius 1, Genius 2, Volume, Upper On, Lower On, Dynamic Keying, Portamento, Upper Octave
Bass Tabs	Bass Sustain, Bass 16, Bass 8, Ensemble Bass, Pedal Genius, Pedal Drawbars
Lower Tabs	Lower Genius, Vocal Ensemble, Strings 8, Strings 4, String Vocal Sustain, Flute 8, Flute 4, Flute 2 2/3, Flute 2, Lower Flute Sustain, Lower Master On/Off, Lower Flute Drawbars
Upper Tabs	Upper Flute Sustain, Flute 16, Flute 8, Flute 5 1/3, Flute 4, Flute 2 2/3, Flute 2, Flute 1 1/3, Flute 1, Flute Percussion, String Vocal Sustain, Strings 16, Strings 8, Strings 4, Vocal Ensemble, Upper Genius, Upper Master On/Off, Upper Flute Drawbars
Tab Controls	Flute Vibra Trem Slow/Fast, Flute Chorus, Chorus/Celeste, Flute Tab Select Lowrey or Jazz, Master Lower/Upper Tabs, Theatre Drums
Genius	Assign sounds from the menu of 285 Genius sounds to the Golden Harp Genius, Solo Genius 1-2, Orchestral Genius 1-2, Upper Genius tab, Lower Genius tab, and Pedal Genius tab.
Touch Bar	Programmable Touch Bar (19 Selectable Functions)
Music Recorder	Record/Playback SU Performance, Playback General MIDI, General MIDI w/Lyrics, Capture Presets
Graphic Mixer	Volume Controls: Master, Bass, Orch Plus, Lower, Upper String/Vocal, Reverb Amount
Feature Lock	Control, Accompaniment, Tempo, Harmony
Golden Harp	Eight Arpeggio Patterns, Golden Harp Genius
Harmony	Seven Harmony Selections: AOC, Duet, 3 Part, 4 Part, Country, Polka, Block
Sound Effects	Assign sounds from 141 Sound Effect & Drum Sounds to certain lower keyboard keys and Select sounds for the Theatre Drums feature
Keys & Pedals	Two 61-Note Upper and Lower Manuals, 13-Note Spinet Style Pedalboard
Connections	Stereo Headphone, Microphone (separate volume controls) MIDI In-Out-Thru, Aux Out/In Right-Left/Mono, Video Out
Dimensions Ship Weight	48" Wide x 29.5" Deep x 46" High with Music Rack removed, 54" with Music Rack Installed 366 lbs. - Including Bench
Cabinet	Natural Wood Veneers & Solids, Walnut or Oak Finish, Wood Roll Top, Lighted Music Rack Extender
Bench	Deluxe Padded Bench, Opens for Music Book and Disk Storage

Performer
LOWREY